











Allen Kadow—Manager



Lift Solution Engineers, Purchasing and Operations Co-Located

### Lift Solutions

Manitowoc Cranes Lift Solutions Team is a group of sales, engineering, purchasing and operations professionals dedicated to helping customers with unique applications for lattice crawler product. Whether your requirement is for a new or 40-year-old product, the Lift Solutions Team is your answer.

### What is a Lift Solution?

### <u>IS</u>

- New application
- Customization of existing product
- Approval
- Customer supplied attachment
  - Special Lift
  - Travel
  - Wind
- Liftplan/erection procedure
- Custom load chart
- Accident investigation support
- Structural modification

- <u>IS NOT</u> Structural repair (contact CraneCARE)
- Obsolete part for current or past production model (contact CraneCARE)
- New serial numbered attachment

Manitowoc knows that not every job is the same and neither is every crane. The Lift Solutions Team will configure your crane to exact requirements, making your Manitowoc crane the perfect tool for your job.

The following pages detail previous Lift Solutions. If you would like to discuss an application you see here, a modification to what is shown, or a new customization, contact your local dealer or the Lift Solutions Team directly at:

### (920) 683-6462

### Or

### allen.kadow@manitowoc.com

This page left intentionally blank.

### Contents

Anti Two Block (ATB)	6	Operator's cab, elevated	32
Approval letters	7	Pedals, travel	33
Auto lube	8	Personnel handling	34
Autotrol	9	Pile lead adapter	35
Bail limits	10	Public Address (PA) system	36
Barge tie down	11	RCL, external display	37
Boom rollers	12	RCL, light bar	38
Cameras	13	Rope guards	39
Clamshell package	14	Rope guides	40
Collector ring	15	Set-up remote control	41
Counterweight	16	Spark arrestor	42
Custom capacity charts	17	Swing limiter	43
Detachable upper boom point	18	Tagline	44
Emergency backup power	19	Walkways, carbody	45
Generator assembly	20	Walkways, rotating bed	46
Horn, compressed air	21	Wind speed alarm	47
Hydraulic equipment/attachments	22		
Lifting arrangements	23		
Lift plan/erection procedure	24		
Lights, boom position	25		
Lights, boom	26		
Lights, rotating bed	27		
Lights, service	28		
Load block/weight ball	29		
Mast lay down	30		
Operator's cab, cage	31		

# Anti Two Block (ATB)

### Description

Anti Two Block prevents operator from running load block/weight ball into boom point. Machine comes standard with one ATB per point. Consists of electrical and mechanical components including junction boxes, switch, chain, weight and cable reel when required.



### **Existing models**

4100W, 999, 15000, 2250, 18000

### Notes

### **Approval letters**

### Description

Letters approving special lifts, wind conditions, rigging, travel or customer supplied equipment.

Nanıt	owoc		Manitowood Cranes 2401 South 30th Street PO Box 70 Maritowood, WY 54221-0070 7 920 684 6621 F 920 683 6277 www.marifilowoc.com
March 12, 20	13		
Mr. Sinan Sinan heavy L	RLLC		
Subject: 180	00 with 21000 MAX-EF	One Time Lift Approval	(LS # 801049)
Dear Mr. Sina	in:		
Attached is th	e review of your reques	e.	
Mast MAX, Crans Carbs Boom Capa Load Data: Require Load Data: Require Load Data: Require Load Boom Agains approvide adherence to 1. Custo 2. The is contec 3. Side 1 4. Riggin	E ER: Length: Length: Counterweight: Counterweight: Counterweight: Rigging Assembly: aty Count: seted Capacity: Radus: Angle: a reviewed the above o al to this request based the following requirememer mer certifics that the fill and subjected to the boo g weight including bloc ved load.	SIN 18001092 SIN 18001092 SIN 21000099 54.9m Boom N 42.7m Mast No 380 090 kg at 145 150 kg A05377 8661-AM 8574-A 420 000 kg 22m 68.7 degrees onfiguration for the 18000 1 on the customer's submits nits. t does not exceed the load th tagilines or other metho oom must not exceed 1 perc k, crane wire rope, and all	. 56 Bm position with 21000 MAX-IER for a one time lift and di crane configuration and their strict listed above. ds and swing speed shall be slow and ont of the lifted load. (gging used shall be instuded as a part of the sity chart 8541-AM and the Operator's Manual
5. All op must			
5. All op must 6. Grade We hope that	this satisfies your requi	rements and are happy to h wai please contact Manitov	ave assisted you in this situation. If you have oc Cranes.
5. All op must 1 6. Grade We hope that	this satisfies your requi in regards to this appro	rements and are happy to h well please contact Manitov	ave assisted you in this situation. If you have oc Cranes.
5. All op must 1 6. Grade We hope that any questions	this satisfies your requir in regards to this appro	rements and are happy to h wal please contact Manitov	ave assisted you in this situation. If you have oc Cranes,
5. All op must 8. Grade We hope that any questions Sincerely, Drian Nysse Engineering M	in regards to this appro	rements and are happy to I wai please contact Manitov	ave assisted you in this situation. If you have oc Cranes.
5. All op must 0. Grade We hope that any questions Sincerely. Brian Nysse Engineering M Lattice Crane	in regards to this appro	rements and are happy to h yval please contact Manitov	ave assisted you in this situation. If you have not Cranes.

### **Existing models**


All

### Notes

### Auto lube

### Description

Automatic lubrication for turntable bearing and/or crawlers is available through a computer controlled system. Consists of a reservoir, pump, divider valves, fittings and tubing.



### **Existing models**


777, 888, 999, 2250, 16000, 18000

### Notes

### Autotrol

### Description

Autotrol allows VICON machines to operate drums as full powered instead of free-fall. Consists of controls, components and fittings.



### **Existing models**

7000

### Notes

Must be used with full range VICON power load lowering. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

# Bail limits, min./max.

### Description

Bail limit switch stops drum operation upon minimum or maximum rope on the drum. Consists of lever, switch and mounting components.



### **Existing models**


111, 555, MLC165, 777, 888, 999, M250, 2250, 16000, 18000, 31000, 3900, 4100W, 4600S3 and S4, 36" Platform Ring, 60' Platform Ring

#### Notes

### **Barge tie-downs**

### Description

Barge tie-downs consist of locations, components and suggested methods of securing the crane to the barge.



#### **Existing models**

777, 999, 16000, 4100W


#### Notes

A barge mounted crane is positively secured to prevent shifting and is subjected to tipping. When not working, crane carbody is anchored with tie-downs to the barge. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### **Boom rollers**

### Description

Boom rollers are designed to keep hoist rope from rubbing lacings on boom. Consist of brackets, bearings, roller and hardware.



### Existing models


888, 999

### Notes

### Cameras

### Description

Cameras allow the operator to view drums, load block from boom point, sides and rear of crane. Camera system consists of multiple camera/light combination units displayed on single or multiple CCTV screens in the operator's cab.



### **Existing models**


2250, 16000, 18000, 21000

### Notes

### **Clamshell package**

### Description

Clamshell package allows the operator to use a bucket or grab to re-handle product. Consists of pressure rollers for front and rear drum, tagline, wire rope guards, capacity chart and programming.



### **Existing models**

555, 777, 14000, 15000


### Notes

Manitowoc recommends machine be equipped with free-fall drums for clamshell operation. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### **Collector ring**

#### Description

Collector ring provides electrical power to components located above the crane turntable bearing. Consists of the collector ring, mounting hardware and junction box.



### Existing models

2250

#### Notes

Collector ring specifications determined by requirements of all electrical components. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Counterweight

### Description

Custom sized counterweight to allow for customer supplied attachments.





### **Existing models**

18000

### Notes

### **Custom capacity chart**

#### Description

Custom capacity charts to complement existing capacity charts or when a capacity chart does not exist.



All

#### Notes

### Detachable upper boom point

### Description

Special detachable upper points for "wind" work, personnel handling, or special lift requirements. Points consist of weldment, sheave(s), RCL and ATB.



### Existing models

777, 14000, 999, 2250, 16000, 18000

### Notes

### **Emergency backup power**

### Description

Emergency backup power allows for operation in the event of main engine failure. Consists of an electric motor, hydraulic pump(s), valves, tubing and controls for independent operation of one of the following: boom hoist, swing and load hoists.





### **Existing models**

777, 14000, 999, 2250


#### Notes

Contact Lift Solutions regarding emergency operation. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### **Generator assembly**

### Description

Diesel generator set mounted to machine to power any or all of the following: cold weather package, boom lights, rotating bed lights, boom position lights. Consists of a diesel generator, controls, mounting frame and load center.



### Existing models

222WC, 777, 14000, 999, 2250, 16000, 18000


### Notes

Size and voltage depends on customer electrical requirements. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Horn, compressed air

### Description

Air horn kit consists of compressor, air tank, solenoid valve, horn, tubing and fittings.



### **Existing models**


18000

#### Notes

### Hydraulic equipment/attachments

### Description

Machine supplied hydraulic power to run customer supplied equipment. Consists of engineered attachment points, stability calculations, special reeving, hydraulic reservoir, piping, valves and connection points.



#### **Existing models**

3900, 4100W, 4600, 1015, 777, 14000, 2250


#### Notes

Customer to supply Lift Solutions with manufacturer specifications for flow, pressure and/or weights. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Lifting arrangement

### Description

Lift arrangements allow customer to handle complete machine or components. Consists of engineered lift points, rigging components and sling design.



### **Existing models**


222WC, 555, 777, 14000, 888, 999, 2250

### Notes

# Lift plan/erection procedure

### Description

When the job site has space restrictions, Lift Solutions can lay out your lift or generate assemble/disassemble in the air procedures.



### Existing models


All

### Notes

### Lights, boom position

#### Description

Boom position lights on boom point, jib point, fixed mast or jib strut. Consists of light(s), wiring, mounting hardware and battery charger with power receptacle.



#### **Existing models**

777, 14000, 999, 2250, MAX-ER 2000, 16000, 18000, 21000

### Notes

# Lights, boom

### Description

Boom lighting consists of multiple lights mounted on the boom to illuminate areas under the boom. Power for lights come from generator assembly.



#### **Existing models**

222WC, 555, 777, 14000, 999, 2250, 16000, 18000

### Notes

Number and type of lights to be specified by customer. See generator assembly for description. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

# Lights, rotating bed

#### Description

Rotating bed lighting consists of multiple lights mounted on the rotating bed to illuminate areas around the machine. Power for the lights come from the generator assembly.



#### **Existing models**

222WC, 555, 777, 14000, 999, 2250, 16000


#### Notes

Number and type of lights to be specified by customer. See generator assembly for description. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Lights, service

### Description

Service lights on rotating bed to illuminate components for service work.



### **Existing models**

18000


#### Notes

Number and type of lights to be specified by customer. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Load block/weight ball

### Description

Load block/weight ball designed to customer requirement: overhaul weight, duplex hook, quick reeve and GOST approved retention of hook nut.





#### **Existing models**


All

### Notes

### Mast lay down

### Description

Design to allow for fixed mast to lay down on boom for moving under obstructions. Consists of special procedures and support components.



### Existing models

4600 Ringer, 18000

### Notes

### Operator's cab, cage

### Description

Wire cage to protect operator cab glass while performing clamshell, dynamic compaction or drop ball work.



### **Existing models**

1015

### Notes

### **Operator's cab, elevated**

### Description

Elevated operator's cab allows operator to see over piers, boat rails or tunnel jobs. Consists of ladders, handrails, platforms and rotating bed modification to support the structure.





### **Existing models**

888, 999, 2250, 4100W

### Notes

Contact Lift Solutions with cab height requirements. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### Pedals, travel

### Description

Foot pedals allow operator to travel while booming, swinging or running hoist drums. Consists of foot pedals mounted in cab floor plate.



### **Existing models**

555, 777, 14000, 2250

### Notes

### **Personnel handling**

### Description

Consists of a drum with wire rope, rope guides, special detachable upper boom point with single sheave for whip line and second single sheave for personnel handling line. Optional emergency lowering capability available for customer supplied or Manitowoc supplied emergency backup power.



### Existing models

777, 14000, 999, 2250, 16000


### Notes

See Emergency Backup Power for related descriptions regarding this solution. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

### **Pile lead adapter**

#### Description

Pile lead adapters are designed to connect fixed leads to a boom top. Consists of weldment and/or links and optional hydraulics to control batter.



#### **Existing models**

555, 777, MLC165, 14000, 2250


### Notes

Contact Manitowoc with the make and model of your pile driver for an adapter to match. See hydraulic equipment/attachments for hydraulic description. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

# Public Address (PA) system

### Description

PA system allows communication from the operator to support crew. Consists of cab mounted microphone, loudhailer and speaker.



### **Existing models**

777

### Notes

### Rated Capacity Limiter, external display

### Description

Externally mounted display of RCL/RCI data for crew visibility. Consists of display screen visible to work crew.



#### **Existing models**

222, 555, 777, 14000

### Notes

# Rated Capacity Limiter, light bar

### Description

Light bar displaying a green/yellow/red light indication based upon percentage of rated capacity.




MLC165, 14000, 31000

### Notes

### Rope guards

### Description

Designed to keep hoist rope on the sheaves.



### **Existing models**

777, 2250

### Notes


Contact Manitowoc regarding machine operation for guidance on rope guards. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

# **Rope guides**

### Description

Rope guides are designed for all rigging to keep rope clear of crane structure and to control fleet angles.





### **Existing models**

All

### Notes

### Set-up remote control

### Description

Special design remote control, wired or wireless, to control the assembly or disassembly of the crane.



#### **Existing models**


16000

#### Notes

### Spark arrestor

### Description

For job sites requiring spark arrestor technology.



### **Existing models**

555, 14000, 999, 16000


### Notes

For Tier III and lower engines. For pricing and lead time, please contact your local dealer or the Lift Solutions Team with specific product requirements.

## Swing limiter

### Description

To set swing boundaries, electronic and mechanical swing limits are available for your crane.



#### **Existing models**


555, 14000, 888, 999, 15000, 2250, 16000, 18000

### Notes



### Description

For clamshell/duty-cycle work where bucket or grab control is required. Consists of spring loaded or hydraulic tagline.



#### **Existing models**


777, 1400, 999, 2250, 16000, 18000

### Notes

## Walkways, carbody

### Description

Special walkways are available on carbody to access machinery or perform required inspections.



### Existing models

999

#### Notes

## Walkways, rotating bed

### Description

Special walkways with handrails are available on rotating bed to access machinery or perform required inspections.



### Existing models


### 2250, 18000

#### Notes

# Wind speed alarm

#### Description

An audio alarm is available to enhance the standard wind speed indicator.



### Wind Speed Indicator

Wind speed icon displays the steady wind speed and maximum gust wind speed. The indicator is reset with Confirm button in **level 3**.

12 крз	
33 KPS	

Exis	ting	mod	els

2250

### Notes



This document is non-contractual. Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories and may not include all standard equipment.